

RELEASE

Liquid Flatware Presoak

RELEASE FLATWARE PRESOAK uses a highly concentrated formula that loosens crusted-on food soils & debris, & improves flatware washability when used as a presoak before dishmachine washing.

- Loosens Crusted-on Food Debris from Tableware & Utensils
- Improves Washability
- For Use Prior to Machine Dishwashing



SAY GOODBYE TO GREASY FLATWARE & HELLO TO SINGLE-WASH CYCLES



WHERE TO USE

- COMMERCIAL DISHMACHINES

DIRECTIONS

READ ENTIRE PRODUCT LABEL PRIOR TO USE.

Dilute 1 - 2 OZ to 1 GL of water into a soak tub. Add flatware & utensils to tub & let soak 10-15 minutes before washing.

TECHNICAL DETAILS

| SIZE | PACKAGING | LIQUID COLOR |
|------|-------------|--------------|
| 1 GL | 4/1 GL CASE | CLEAR |
| 5 GL | PAIL | CLEAR |

Have a whole lot more to clean?

Call us today to learn about our line of products!

1-877-4-EMULSO

2750 kenmore avenue, tonawanda, ny 14150 | Emulso.com